FTI-GMK2 Type 1A - Vehicle Coverage & Preparation Notes

F	RSTECH, LLC. SUPPORT - 1(888) 820-3690, EXT. 203
,	SUPPORT - 1(888) 820-3690, EXT. 203

TP SUPPORT - 1(888) 820-3690, EXT. 20:										
Make	Model	Year	Install	CAN	Lights	RAP	Trunk	I/O Changes		
DL-GM7					Park / Auto			Green White/Blue		
Buick	Encore Flip-key	2013-16	Type 1	ВСМ	H					
Buick	LaCrosse Flip-key	2010-16	Type 1	BCM	Н					
Buick	Regal Flip-key	2011-16	Type 1	ВСМ	H					
Buick	Verano Flip-key	2012-17	Type 1	BCM	Н					
Chevrolet	Camaro Flip-key	2010-15	Type 1	BCM	Н					
Chevrolet	Colorado Flip-key	2015-16	Type 1	всм	Н					
Chevrolet	Cruze/Cruze Ltd	2010-16	Type 1	BCM	Н					
Chevrolet	Equinox Flip-key	2010-17	Type 1	всм	Н					
Chevrolet	Impala Flip-key	2014-16	Type 1	ВСМ	Н					
Chevrolet	Malibu Flip-key	2013-16	Type 1	ВСМ	Н					
Chevrolet	Orlando Flip-key	2011-14	Type 1	BCM	Н					
Chevrolet	Silverado 1500 Key	2014-16	Type 1	ВСМ	H					
Chevrolet	Silverado 2500/3500 Key	2015-16	Type 1	BCM	H					
Chevrolet	Sonic Flip-key	2012-16	Type 1	BCM	H					
Chevrolet	Suburban Key	2015-16	Type 1	BCM	H					
Chevrolet	Tahoe Key	2015-16	Type 1	BCM	H					
Chevrolet	Trax Flip-key	2013-16	Type 1	BCM	H					
GMC	Canyon Key	2015-16	Type 1	BCM	Н					
GMC	Sierra 1500 Key	2014-16	Type 1	всм	Н					
GMC	Sierra 2500/3500 Key	2015-16	Type 1	BCM	Н					
GMC	Terrain Flip-key	2010-17	Type 1	всм	Н					
GMC	Yukon Key	2015-16	Type 1	BCM	Н					
	JI.		l	II .	ll l	l J		IL J		

Hey! Read this stuff before you start the installation...

Firmware:

Covered vehicles use BLADE-AL(DL)-GM7, flash module and update the controller firmware before

Install:

Type 1 vehicles attain CAN data from the BCM, which requires the **CAN/BCM** configuration of the CAN source connectors on the harness assembly. The vehicle BCM is located left of the steering column (LSC) in all **except** the **Verano**, **Cruze**, and **Orlando**, where it's on the passenger side of the center console (**PCC**)

Lights:

Type H lights are incorporated in the harness and utilize the vehicle hazard lights for visual display of runtime status/diagnostics. Re-pinning of the CM I/O (gray) harness is required if you wish to use hazard lights, traditional parking light option is noted in the installation notes and diagram. Use of hazards also requires that you reconfigure the POC for one of the following hazard control options, **Hazard1** (POC option #30 (momentary) **or Hazard2** (POC option #23 (latching), depending on hazard switch operation.





