

Make	Model	Year	Install	CAN	Lights	Type	BCM	Configuration
DL-GM7 GMC	Sierra 1500 STD Key AT w/o OnStar w/o OEM Alarm	2014-16	Type 5	Type A	Park / Auto Type A	Key	LSC	Feature Option None

Firmware: This installation uses **BLADE-AL(DL)-GM7**, flash module and update the controller firmware before installing.

Install: **Type 5** installation sources CAN data from the blue connector of the BCM, requiring the use of the 'A-connector', the connector marked 'B' is not used.

Lights: **Type A** lights (standard parking lights) are provided, as are **Type H** (hazard lights), both incorporated in the harness for visual display of runtime status/diagnostics. Re-pinning of the CM I/O (gray) harness is required, regardless of which type you choose to use, both options have been provided for your selection. If you choose hazards you will also need to configure the selected POC for one of the following hazard control options, **Hazard1** (POC option #30 (momentary) or **Hazard2** (POC option #23 (latching), depending on hazard switch operation.

Locks: The CM lock connector is mandatory for this installation type. The harness Assembly is pre-wired provide the necessary analog control.

Lock connector is mandatory for this installation type. :)

FTI-GMT3 - Installation and Configuration Notes



- A** REQUIRED CONNECTION, SEE NOTE ABOVE
- B** REQUIRED CONNECTION
- C** REQUIRED CONFIGURATION - TYPE A
- D** REQUIRED CONFIGURATION - KEY TYPE

•FT-DAS Required for manual transmission.
•BOTH Red & Red/White MUST be connected with high current application.


Jumper Setting

Parking Light	Accessory	Ignition (Default)	(+)Door Trigger In (Default)	(-)Door Trigger In (Default)	Trunk	Starter	Ignition	Accessory (Default)
Parking Light (Default)								

CM7000/7200 Cut loop for A/T




CM900AS/900S Jumper



START
ACC
IGN1



FEATURE COVERAGE													
IMMOBILIZER DATA													
3X LOCK START													
DOOR STATUS													
TRUNK STATUS													
RAP SHUTDOWN													
BRAKE STATUS													
E-BRAKE STATUS													
TACH OUTPUT													
DATA/MUX IGN/ST													
HOOD STATUS													
SECURE TAKEOVER													
PARKING LIGHTS													
HAZARD LIGHTS													●



LED Programming Error Codes

Module LED flashing RED during programming

- 1x - No ACC power, check GREEN connector
- 2x - MUX status not detected, check GREEN connector
- 3x - No IGN, check GREEN connector
- 4x - No HSCAN activity, check BLUE connector
- 5x - No SWC activity, check BLUE connector
- 6x - Wrong SWC message, confirm key has been removed
- 7x - No ACC power, check GREEN connector
- 8x - No immobilizer data, check GREEN & BLADE connectors
- 9x - IGN ON, confirm key has been removed
- 10x - Keysense active, confirm key has been removed
- 11x - No ACC, confirm key is on
- 12x - No IGN, confirm key is on
- 13x - VIN not matching Weblink data, contact engineering

CARTRIDGE INSTALLATION




1 Slide cartridge into unit. Notice button under LED.

2

Ready for Module Programming Procedure.

MODULE PROGRAMMING PROCEDURE




1 Insert key into ignition.




2 Turn key to ON position.




3 Wait, LED will flash BLUE rapidly.




4 Turn key to OFF position.



5 Remove key.



6 LED will turn solid RED.



7 Insert key into ignition.




8 Turn key to ON position.




9 LED will turn OFF.



10 Turn key to OFF position.




11 Remove key.




12 Insert key into ignition.



13 Turn key to ON position.



14 Wait, LED will turn solid BLUE for 2 seconds.



15 Turn key to OFF position.

16

Module Programming Procedure completed.