

Ignition Connector


1

Keysense

2

Main Body ECU


3



TL9 LED Programming Error Codes

- Module LED flashing RED during programming
- 1x - No CAN activity, check harness connections.
 - 2x - No analog Ignition, check harness connections.
 - 3x - No Immobilizer data, check SIL to OBD connection.
 - 4x - VIN received but not in table, contact iDataLink.

CARTRIDGE INSTALLATION



1 Slide cartridge into unit. Notice button under LED.

2

Ready for Module Programming Procedure.

MODULE PROGRAMMING PROCEDURE


NOTE

! IMPORTANT: The hood must be closed.

1 OFF ACC **ON** START Set ignition to ON position.



2 Wait, LED will turn solid RED to confirm that the ignition is ON.



3 Wait, LED will flash BLUE rapidly.



4 OFF ACC ON START Set ignition to OFF position.



5 **WARNING:**
Disconnect power last.
Disconnect module from vehicle.



6



Connect module to computer and proceed with extended programming.

7



WARNING:
Connect power first.
Connect module to vehicle.


8

OFF ACC **ON** START

Set ignition to ON position.




9



Wait, LED will turn solid RED to confirm that the ignition is ON.

10



Wait, LED will turn solid BLUE for 2 seconds.

11

OFF ACC ON START

Set ignition to OFF position.



12

Module Programming Procedure completed.