




**Immobilizer Connector**

1



**Ignition Switch**

2



**Headlight Switch Connector**

3


1			6
7			12

**LED Programming Error Codes**

Module LED flashing RED during programming

- 1x - CAN error, confirm harness connections
  - 2x - Klon data is wrong, redo programming from the beginning
  - 3x - No S-net data, check connections
  - 4x - No VIN data, check connections, confirm vehicle entry
- After Klon:
- If module LED stays RED, redo programming from the beginning of the process, remember to close/open door.
  - 2x - Klon failure, redo programming, see note above.

## CARTRIDGE INSTALLATION




1 Slide cartridge into unit. Notice button under LED.

2


Ready for Module Programming Procedure.

## MODULE PROGRAMMING PROCEDURE

1




Close driver door.



Re-open driver door to wake up data bus.

2




Turn ignition to ON position.

3




Wait, LED will flash BLUE rapidly.

4



Turn ignition to OFF position.

5




**WARNING:**  
Disconnect power last.  
Disconnect RS from vehicle.

6




Connect RS to computer and proceed with extended programming.

7




**WARNING:** Do not press RS programming button.  
Connect power first.  
Connect RS to vehicle.

8




Turn ignition to ON position.

9



Wait, LED will turn solid BLUE for 2 seconds .

10



Turn ignition to OFF position.

11



Press UNLOCK on the OEM remote.



If the vehicle is equipped with a power liftgate: Open and close the power liftgate with the OEM keyfob.

12

Module Programming Procedure completed.