FTI-TLP3: Vehicle Coverage and Preparation Notes

F	RSTECH, LLC. SUPPORT - 1(888) 820-3690, EXT. 203
	SUPPORT - 1(888) 820-3690, EXT. 203

Make	Model	Year	Install	ECU	Lights	DCM	Trunk/ Hatch	I/O Changes	
DL-TL7					Park / Auto			Green White/Blue	
Lexus	RX450h PTS AT	2016-21	Type 1s	DKP	Yes	No	Red (5)	Χ	
			(starter)						

This installation requires **BLADE-AL(DL)-TL7** firmware, flash module and update controller before beginning the installation.

Install Type 1S: Main Body ECU, driver side kick panel area, optional trunk/hatch connection, no DCM interface required.

CAN: Vehicle CAN data is gathered through the 30-pin connection at the Main Body ECU, no other connections are required.

Starter: +12V starter connection is required at pin-9 of the 35-pin connector of the Hybrid ECU, please insert the included wire into position #6 of the CN1 connector and connect as illustrated.

Lights: Parking light and auto-light control are handled using the pre-terminated **green/white** wire bundled with the **BLADE** connector. Remove the (-) pk light wire from the controllers **gray** I/O connector and replace with the one specified, for status and diagnostic reporting.

Locks: This installation type requires additional connections to the vehicle door locks to ensure proper synchronization with the OEM remotes. *The 6-pin lock connector is required for correct operation*. Connect to the control module lock output port.

Idle Mode is not a supported feature of the FTI-TLP3 Harness: The Idle Mode feature which allows the user to exit a running has been excluded from the FTI-TLP3 harness wiring. If this feature is desired, please refer to the full BLADE installation diagram for the applicable wiring and make the required connection to the vehicle PTS button.


TAKEOVER NOT SUPPORTED: THE VEHICLE WILL SHUT DOWN UPON OPENING DRIVER'S DOOR


FTI-TLP3: Installation and Configuration Notes

- A CONNECTION REQUIRED
- **B** CONNECTIONS REQUIRED
- C OPTIONAL CONNECTION
- D NOT REQUIRED
- E CONNECTION REQUIRED



	FEATURE COVERAGE																			
		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		
IMMOBILIZER DATA	3X LOCK START	PTS CONTROL	ARM OEM ALARM	DISARM OEM ALARM	A/M CONTROL FROM OEM REMOTES	A/M RS CONTROL FROM OEM REMOTE	PRIORITY UNLOCK	DOOR LOCK	DOOR UNLOCK	TRUNK/HATCH RELEASE	DOOR STATUS	TRUNK STATUS	HOOD STATUS	тасн оитрит	BRAKE STATUS	E-BRAKE STATUS	PARKING LIGHTS	AUTOLIGHT CONTROL		








ALL IN ONE LEXUS/TOYO

Patent No. US 8,856,780 CA 2759622

Page 86 of 87 COM-BLADE-AL(DL)-TL7-EN Doc. No.: ##75340## 20210414

CARTRIDGE INSTALLATION



Slide cartridge into unit. Notice button under LED.

2

Ready for Module Programming Procedure.

MODULE PROGRAMMING PROCEDURE

NOTE

I IMPORTANT: The hood must be closed.

1 BROINE START STOP X2

Push start button twice [2x] to ON position.

2

Wait, if LED turns solid BLUE for 2 seconds, proceed to step 7.

If LED flashes BLUE rapidly, proceed to step 3.

3 ENGINE START STOP

Push start button once [1x] to OFF position.

4

Wait, LED will turn solid RED. (This may take up to 5 minutes.)

5 ENGINE START STOP X2

Push start button twice [2x] to ON position.

6

Wait, LED will turn solid BLUE for 2 seconds.

7 PRINTED X 1

Push start button once [1x] to OFF position.

8

Module Programming Procedure completed.