# FTI-CDK2: Vehicle Coverage and Preparation Notes

F	RSTECH, LLC. SUPPORT - 1(888) 820-3690, EXT. 203
- 1	SUPPORT - 1(888) 820-3690, EXT. 203

Make	Model	Year	Install	CAN	Lights	RAP	POC	I/O Changes
DL-CH4					Park / Auto			Green White/Blue
Dodge	Magnum Tip Start	2008-09	Type 1	WIN	Type A	DDP		

**Firmware:** Vehicle requires **BLADE-AL(DL)-CH4** firmware, flash module and update the controller firmware before beginning the installation.


**CAN:** In the event that troubleshooting is necessary, CAN connections are located in the connector at the vehicle WIN (Wireless Ignition Node).


**Lights: Type A** MUX type parking lights are populated in the supplied 6-pin headlight switch connector on the harness assembly, properly secure the unused 10-pin connector for safety

**RAP:** RAP shutdown handling for all other covered vehicles is at the driver door pin wire, *purple* wire located in the driver kick panel harness, circuit tests ( - ) negative with door open.

# FTI-CDK2 - Installation and Configuration Notes

- A RAP shutdown connection, configure POC for RAP (option #31).
- B WTS (Wait to start) for diesel applications.
- Connection not required.










# ALL IN ONE CHRYSLER/DODGE/JEEP


Patent No. US 8,856,780 CA 2759622

COM-BLADE-AL(DL)-CH4-EN

Doc. No.: ##70115## 20200320

## MODULE PROGRAMMING PROCEDURE






## WARNING: READ BEFORE REMOTE STARTING THE VEHICLE

## **IMPORTANT**

I All vehicle doors must be closed and locked prior to remote start sequence. Failure to comply will result in remote starter malfunction.

## TAKE OVER PROCEDURE - TO THE VEHICLE OWNER

# NOTE I All vehicle doors must be closed and locked prior to remote start sequence. TIME RESTRICTI ON COMING UP! Press UNLOCK on after-market remote. TIME RESTRICTION Within 45 SECONDS from previous step: Open vehicle door. Enter vehicle.





## **ALL IN ONE** CHRYSLER/DODGE/JEEP

20200320

Doc. No.: ##70115##

Patent No. US 8,856,780 CA 2759622

COM-BLADE-AL(DL)-CH4-EN

# MODULE PROGRAMMING PROCEDURE - PUSH TO START DO NOT PRESS BRAKE PEDAL Push start button once [1x] to OFF position. Press UNLOCK on the OEM remote.

		Re-open driver door to wake up data bus.
2	STATE X2	DO NOT PRESS BRAKE PEDAL
		Push start button twice [2x] to ON position.
3		LED will turn solid RED.
4		Within 5 seconds, LED will flash BLUE rapidly.

Close driver door.

Wait, LED will turn solid BLUE for 2 seconds.

Module Programming Procedure completed.

# WARNING: READ BEFORE REMOTE STARTING THE VEHICLE

### **IMPORTANT**

All vehicle doors must be closed and locked prior to remote start sequence. Failure to comply will result in remote starter malfunction.

## TAKE OVER PROCEDURE - PUSH TO START - TO THE VEHICLE OWNER

# NOTE All vehicle doors must be closed and locked prior to remote start sequence. TIME RESTRICTI ON COMING UP! Press UNLOCK on after-market remote. TIME RESTRICTI IN Within 45 SECONDS from previous step: Open vehicle door. Enter vehicle.

