

FIRSTECH, LLC.
SUPPORT - 1(888) 820-3690, EXT. 203

Hood: Hood status wire is available at the vehicle BCM, connector C1, pin #11 (**violet/blue**).

• FT-DAS Required for manual transmission.
 • BOTH Red & Red/White MUST be connected with high current application.

Jumper Setting			
Parking Light			(+)Door Trigger In
Accessory			(-)Door Trigger In (Default)
Ignition (Default)			
Trunk			Starter
Starter			Ignition
Parking Light (Default)			Accessory (Default)


CM7000/7200

Cut loop for A/T












CM-900S/900AS











CM900AS/900S Jumper

START
ACC
IGN1



MODULE PROGRAMMING PROCEDURE - WITH KLON

- 1  Close driver door.
 Re-open driver door to wake up data bus.
- 2  Press UNLOCK on OEM remote.
If the vehicle is not equipped with an OEM remote, press the module programming button.
- 3  Wait, LED will flash BLUE once [1x].
- 4  Turn key to ON position.
- 5  Wait, LED will turn solid RED.
- 6  Turn key to OFF position.
- 7  Remove key.
- 8  Insert key into ignition.
- 9  Turn key to ON position.
- 10  Wait, LED will flash BLUE.

- 11  Turn key to OFF position.
- 12  **WARNING:**
Disconnect power last.
Disconnect RS from vehicle.
- 13  Connect RS to computer and proceed with extended programming.
- 14  **WARNING:** Do not press RS programming button.
Connect power first.
Connect RS to vehicle.
- 15  Turn key to ON position.
- 16  Wait, LED will turn solid BLUE for 2 seconds.
- 17  Turn key to OFF position.
- 18  Turn key to START position.
- 19  Turn key to OFF position.
- 20  Module Programming Procedure completed.

WARNING: READ BEFORE REMOTE STARTING THE VEHICLE

IMPORTANT

- All vehicle doors must be closed and locked prior to remote start sequence. Failure to comply will result in remote starter malfunction.

TAKE OVER PROCEDURE - TO THE VEHICLE OWNER

NOTE

- All vehicle doors must be closed and locked prior to remote start sequence.




TIME RESTRICTION COMING UP !

1



Press UNLOCK on after-market remote.

2



TIME RESTRICTION

Within 45 SECONDS from previous step:

Open vehicle door.
Enter vehicle.
Close vehicle door.
Insert key into ignition.
Turn key to ON position.
Press and release BRAKE pedal.

3

Take over procedure completed.



Failure to follow procedure within time restriction will result in vehicle engine shutdown.