

E No Onstar/OEM Alarm requiere un pulso ACC con desarmado para controlar adecuadamente el sistema de alarma OEM. Establezca la opción de función 1-11 en la opción 3 (Pulso ACC, mismo tiempo que pulso desarmado)

Códigos de error de programación de LED

- El LED del módulo parpadea en ROJO durante la programación
- 1x - Sin alimentación ACC, verifique el conector VERDE
 - 2x - Estado MUX no detectado, verificar conector VERDE
 - 3x - Sin IGN, verifique el conector VERDE
 - 4x - Sin actividad HSCAN, verifique el conector AZUL
 - 5x - Sin actividad SWC, verifique el conector AZUL
 - 6x: mensaje SWC incorrecto, se ha eliminado la clave de confirmación
 - 7x - Sin alimentación ACC, verifique el conector VERDE
 - 8x - Sin datos del inmovilizador, verifique los conectores VERDE Y BLADE
 - 9x - IGN ENCENDIDO, la clave de confirmación ha sido eliminada
 - 10x - Keysense activo, confirmar clave ha sido eliminada
 - 11x - Sin ACC, la tecla de confirmación está activada
 - 12x - Sin IGN, la tecla de confirmación está activada
 - 13x - VIN no coincide con los datos del enlace web, póngase en contacto con el departamento de ingeniería

CARTRIDGE INSTALLATION




1 Slide cartridge into unit. Notice button under LED.


2

Ready for Module Programming Procedure.

MODULE PROGRAMMING PROCEDURE - WITH KLON




1 Close driver door. Re-open driver door to wake up data bus.



2 Insert key into ignition.




3 Turn key to ON position.



4 Wait, LED will turn solid RED.




5 Turn key to OFF position.



6 Remove key.




7 LED will turn OFF.



8 Insert key into ignition.




9 Turn key to ON position.




10 Wait, LED will flash BLUE rapidly.




11 Turn key to OFF position.




12 Remove key.




13 **WARNING:** Disconnect power last. Disconnect module from vehicle.



14 Connect module to computer and proceed with extended programming.




15 **WARNING:** Do not press module programming button. Connect power first. Connect module to vehicle.




16 Close driver door. Re-open driver door to wake up data bus.



17 Turn key to ON position.



18 Wait, LED will turn solid BLUE for 2 seconds.



19 Turn key to OFF position.

20

Module Programming Procedure completed.