

Make	Model	Year	Install	BCM	Lights	Locks	POC 1	I/O Changes
DL-NI4 Nissan	Versa Intelli-Key AT	2007-11	Type 3	LSC	Park / Auto NI-LOCK	DATA	Hazard1/2	Green White/Blue

Intstall **Type 1** requires **BLADE-AL(DL)-NI4**, flash module and update the controller firmware before beginning the installation.

**I/O Changes:** Each vehicle in this installation group have different configuration requirements for proper handling of ACC and START circuit handling. Please ensure that the appropriate changes have been made before testing. **The required changes are listed below.**

**Intelli-Key Wiring:** Additional wiring and relay are required. See page 3 of this document for additional location and interface requirements.

**CM7000/7200 I/O Changes:**

**Optional Hazard Light Control:**

**NI-LOCK** harness **green/white** is pre-wired for hazards, connect harness wire to the controller POC1 (**blue/white**), additional configuration required. Vehicles equipped with a **MOMENTARY** activation switch require that POC1 be configured for **Hazard light** (POC option #30), if the switch is **LATCHING** type you will use **Hazard light 2** (POC option #23).

**Auto-Light OFF:**

**NI-LOCK** harness **orange** is pre-wired for Auto-light shut off, if the vehicle is equipped with auto-lights connect CM REARM output (**orange**) to **orange** wire in harness.

**D** **NI-LOCK harness configuration:** Configure Double Pulse Unlock (**feature 1-04, option 2**) Vehicle lock functions are handled through data, additional harness configuration is not required.

**FTI-NSK1: Installation and Configuration Notes**

- A** CUTS REQUIRED - INSULATE AFTER CUTTING
- B** REQUIRED CONNECTION - USE JUMPER IF NO IMMOBILIZER
- C** CONNECT AS ILLUSTRATED
- D** CONNECT AS ILLUSTRATED
- E** CONNECT AS ILLUSTRATED





FEATURE COVERAGE																			
IMMOBILIZER DATA	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
PRIORITY UNLOCK	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
DOOR LOCK	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
DOOR UNLOCK	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
ARM OEM ALARM	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
DISARM OEM ALARM	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
TRUNK/HATCH RELEASE	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
A/M ALARM CTRL	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
A/M RS CONTROL	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
HOOD STATUS	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
DOOR STATUS	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
TRUNK STATUS	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
RAP SHUTDOWN	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
BRAKE STATUS	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
E-BRAKE STATUS	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
TACH OUTPUT	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
SECURE TAKEOVER	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
PARKING LIGHTS	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
HAZARD LIGHTS	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

•FT-DAS Required for manual transmission.  
•BOTH Red & Red/White MUST be connected with high current application.

**Jumper Setting**

**CM7000/7200** **CM-900S/900AS**

**CM900AS/900S Jumper**



**POC1 - must be set for HAZARD1/2 (S-#2-01-30 or 23)**

**LED Programming Error Codes**


Module LED flashing RED during programming

- 1x - No HSCAN activity, OBD-II connector
- 2x - No immobilizer data, check connectors
- 3x - N/A
- 4x - No IGN, check circuit power and connections
- 5x - Immobilizer data error, check connections and ground
- 6x - VIN error, confirm vehicle matches Weblink input

# FTI-NSK1-NI4 Type 3: Supplemental Intelli-Key Wiring Diagram


**A** Connector illustrations depict the wire-side view of the connector at the Intelli-Key module, position is accurate to this view.

**B** FT-RLY-10A is a compact, pre-wired relay accessory, wire as illustrated if available. If you are using a standard Bosch type relay, the illustrations utilize consistent color coding for the required connections.




Make	Model	Year	Intelli-Key Module Location
Nissan	Versa Intelli-Key	2007-11	(3) Behind glove box, left <b>Pin #6 - yellow</b>


## \*Tic-Tac-Toe




### **A** Intelli-key Module 3



### **B** FT-RLY-10A



## CARTRIDGE INSTALLATION



1 Slide cartridge into unit. Notice button under LED.


2

Ready for Module Programming Procedure.



## MODULE PROGRAMMING PROCEDURE

### NOTE

I To complete this procedure, use one regular key or one valet key.




II When programming, all key fobs must be located at least 10 feet away from the vehicle.




1 Insert key into ignition.

2




Turn key to ON position.

3



Wait, LED will turn solid BLUE for 2 seconds.

4



Turn key to OFF position.

5

Module Programming Procedure completed.