


X1 MAX 10-Pin Hardwire Connector (FT-HRN-X1-OBD)



X1 MAX Starter Kill Note

Things to know:

- 1.) Starter Kill is configured by default and assigned to POC 3 (blue wire).
- 2.) Starter Kill is toggled on and off by sending lock and unlock commands from the Drone app and not by sending the AUX 1 command.

Repurposed ALCA 10-Pin Connector

