


CARTRIDGE INSTALLATION



1 Slide cartridge into unit. Notice button under LED.

2

Ready for Module Programming Procedure.


MODULE PROGRAMMING PROCEDURE

NOTE


1 **IMPORTANT:** The hood must be closed.




1 Use the BLACK key only. DO NOT use the GRAY valet key.



2 Insert key into ignition.




3 Turn key to ON position.




4 LED will turn solid RED.

5



5 Wait, LED will turn solid BLUE for 2 seconds.

6



6 Turn key to OFF position.

7

7 Module Programming Procedure completed.

