




**Immobilizer Connector** ①



**Ignition Switch** ②




**Headlight Switch Connector** ③



**Códigos de error de programación de LED**  
El LED del módulo parpadea en ROJO durante la programación

- 1x - Error de CAN, confirmar las conexiones del arnés
  - 2x - Los datos de Klon son incorrectos, rehaga la programación desde el principio
  - 3x - No hay datos de S-net, verifique las conexiones
  - 4x - No hay datos de VIN, verifique las conexiones, confirme la entrada del vehículo
- Después de Klon:  
Si el LED del módulo permanece ROJO, rehaga la programación desde el comienzo del proceso, recuerde cerrar/abrir la puerta.  
2x - Fallo de Klon, rehaga la programación, consulte la nota anterior.

## CARTRIDGE INSTALLATION




1 Slide cartridge into unit. Notice button under LED.

2


Ready for Module Programming Procedure.

## MODULE PROGRAMMING PROCEDURE



1 Close driver door.


Re-open driver door to wake up data bus.




2 Turn ignition to ON position.




3 Wait, LED will flash BLUE rapidly.




4 Turn ignition to OFF position.




5 **WARNING:**  
Disconnect power last.  
Disconnect RS from vehicle.




6 Connect RS to computer and proceed with extended programming.




7 **WARNING:** Do not press RS programming button.  
Connect power first.  
Connect RS to vehicle.



8 Turn ignition to ON position.



9 Wait, LED will turn solid BLUE for 2 seconds .



10 Turn ignition to OFF position.



11 Press UNLOCK on the OEM remote.

**!** If the vehicle is equipped with a power liftgate: Open and close the power liftgate with the OEM keyfob.

12 Module Programming Procedure completed.