

Make	Model	Year	Install	CAN	Lights	RAP	POC	I/O Changes
DL-CH4 Chrysler	Town & Country Tip-Start	2011-16	Type 2	WIN	Park / Auto Type A	DDP		Green White/Blue

Firmware: el vehículo requiere firmware **BLADE-AL (DL) -CH4**, módulo flash y actualice el firmware del controlador antes comenzando la instalación.

CAN: En caso de que sea necesario solucionar problemas, las conexiones CAN se encuentran en el conector del vehículo **WIN** (nodo de encendido inalámbrico).


Luces: Las luces de estacionamiento de **Tipo A MUX** se instalan en el conector del interruptor de faros de 6 pines suministrado en el conjunto de arnés, asegure correctamente el conector de 10 pines no utilizado por seguridad.

RAP: El manejo de apagado de RAP para todos los demás vehículos cubiertos se encuentra en el cable de clavija de la puerta del conductor, el cable **púrpura** ubicado en el arnés del panel de protección del conductor, pruebas de circuito (-) negativas con la puerta abierta.


FTI-CDK2 - Notas de instalación y configuración

- A** Conexión de apagado RAP, configure POC para RAP (opción # 31).
- B** WTS (esperar para comenzar) para aplicaciones diesel.
- C** No se requiere conexión.


- FT-DAS Required for manual transmission.
- BOTH Red & Red/White MUST be connected with high current application.





CM7000/7200 **Cut loop for A/T**




CM900AS/900S Jumper



FEATURE COVERAGE																				
IMMOBILIZER DATA	PRIORITY UNLOCK	DOOR LOCK	DOOR UNLOCK	ARM OEM ALARM	DISARM OEM ALARM	POWER LIFTGATE	POWER SLIDING DOOR (L)	POWER SLIDING DOOR (R)	DOOR STATUS	TRUNK STATUS	RAP SHUTDOWN	BRAKE STATUS	E-BRAKE STATUS	TACH OUTPUT	DATA/MUX IGNITION	SECURE TAKEOVER	PARKING LIGHTS			



Wireless Ignition Node



Headlight Switch



Driver kick panel harness











Códigos de error de programación de LED


El LED del módulo parpadea en ROJO durante la programación

- 1x - CAN problema
- 2x - Inmovilizador (confirme que el vehículo está equipado, presione el botón si no)
- 3x - Inmovilizador (confirme que el vehículo comienza con la llave)
- 4x - Sin información VIN
- 5x - VIN no coincide (póngase en contacto con soporte)

MODULE PROGRAMMING PROCEDURE

- | | | |
|----|--|---|
| 1 |  | Close driver door.

Re-open driver door to wake up data bus. |
| 2 |  | Insert key into ignition. |
| 3 |  | Turn key to ON position. |
| 4 |  | LED will turn solid RED. |
| 5 |  | Within 5 seconds, LED will flash BLUE rapidly. |
| 6 |  | Turn key to OFF position. |
| 7 |  | Remove key. |
| 8 |  | Press UNLOCK on the OEM remote.

If vehicle is not equipped with OEM remote, press module programming button. |
| 9 |  | Wait, LED will turn solid BLUE for 2 seconds. |
| 10 | | Module Programming Procedure completed. |

WARNING: READ BEFORE REMOTE STARTING THE VEHICLE

IMPORTANT



- All vehicle doors must be closed and locked prior to remote start sequence. Failure to comply will result in remote starter malfunction.

TAKE OVER PROCEDURE - TO THE VEHICLE OWNER



NOTE


- All vehicle doors must be closed and locked prior to remote start sequence.



- | | | |
|---|---|--|
| 1 |  | Press UNLOCK on after-market remote. |
| 2 |  | TIME RESTRICTION
Within 45 SECONDS from previous step:









Open vehicle door.
Enter vehicle. |

- | | | |
|---|--|--|
| 3 |  | Insert key into ignition. |
| 4 |  | Turn key to ON position.

Wait 2 seconds for key validation. |
| 5 |  | Press and release BRAKE pedal. |
| 6 | | Take over procedure completed. |

! Failure to follow procedure within time restriction will result in vehicle engine shutdown.

MODULE PROGRAMMING PROCEDURE - PUSH TO START

- | | | | | | |
|---|---|--|---|--|--|
| 1 |  | Close driver door. | 5 |  | DO NOT PRESS BRAKE PEDAL
Push start button once [1x] to OFF position. |
| |  | Re-open driver door to wake up data bus. | 6 |  | Press UNLOCK on the OEM remote. |
| 2 |  | DO NOT PRESS BRAKE PEDAL
Push start button twice [2x] to ON position. | 7 |  | Wait, LED will turn solid BLUE for 2 seconds. |
| 3 |  | LED will turn solid RED. | 8 | | Module Programming Procedure completed. |
| 4 |  | Within 5 seconds, LED will flash BLUE rapidly. | | | |

WARNING: READ BEFORE REMOTE STARTING THE VEHICLE

IMPORTANT


- All vehicle doors must be closed and locked prior to remote start sequence. Failure to comply will result in remote starter malfunction.

TAKE OVER PROCEDURE - PUSH TO START - TO THE VEHICLE OWNER



NOTE

- All vehicle doors must be closed and locked prior to remote start sequence.

 TIME RESTRICTION COMING UP !

- | | | | | | |
|---|---|---|---|--|--|
| 1 |  | Press UNLOCK on after-market remote. | 3 |  | DO NOT PRESS BRAKE PEDAL
Push start button twice [2x] to ON position.

Wait 2 seconds for key validation. |
| 2 |  | TIME RESTRICTION
Within 45 SECONDS from previous step:

Open vehicle door.
Enter vehicle. | 4 |  | Press and release BRAKE pedal. |
| | | | 5 | | Take over procedure completed. |
| | | | |  | Failure to follow procedure within time restriction will result in vehicle engine shutdown. |