

Make	Model	Year	Install	CAN	Lights	IGN	RAP	I/O Changes
DL-CH12 Chrysler	200 PTS	2015-17	Type 1A	OBD-II	Park / Auto Type B2	PINK	NO	Green White/Blue N/A

### FIRMWARE:

This installation requires BLADE-AL(DL)-CH12, flash module and update the controller firmware before installing.

### INSTALLATION:

Type 1A vehicles use CAN connections in harness at OBD-II connector, the included CAN extension is not required for this install type.

### IGNITION:

Ignition is available at junction connector located above the driver kick panel, attached to the firewall, vehicle wire is located at pin #19, pink/lt. green, of the 59-pin connector.

## FTI-CDP1 - Installation and Configuration Notes

- A** REQUIRED CONNECTION (OBD-II CAN)
- B** NOT REQUIRED (CAN extension)
- C** NO CONNECTION
- D** REQUIRED CONNECTION (IGN)

•FT-DAS Required for manual transmission.  
•BOTH Red & Red/White MUST be connected with high current application.

**Jumper Setting**



**CM7000/7200** Cut loop for A/T

**CM-900S/900AS**


**CM900AS/900S Jumper**



FEATURE COVERAGE																				
IMMOBILIZER DATA	ARM OEM ALARM	DISARM OEM ALARM	DOOR LOCK	DOOR UNLOCK	PRIORITY UNLOCK	TRUNK/HATCH RELEASE	POWER LIFTGATE	POWER SLIDING DOOR (L)	POWER SLIDING DOOR (R)	SECURE TAKEOVER	DOOR STATUS	TRUNK STATUS	HOOD STATUS	E-BRAKE STATUS	TACH OUTPUT	BRAKE STATUS	GLOW PLUG STATUS	PARKING LIGHTS	HAZARD LIGHTS	A/M CONTROL




**OBD-II connector**



**PTS Button**




**Headlight switch**



**Driver kick panel/firewall junction connector**

Junction connector, above driver kick panel, attached to firewall



**LED Programming Error Codes**


Module LED flashing RED during programming


- 1x - CAN Error
- 2x - Key code not learned
- 3x - No IGNITION
- 4x - No immobilizer, check CAN/key
- 5x - VIN error, check CAN wiring
- 6x - See 4x error
- 7x - KLON error
- 8x - No IGNITION, check connection


## MODULE PROGRAMMING PROCEDURE - PTS


### NOTE

I **IMPORTANT:** The hood must be closed.


**1**  Close driver door.  
Re-open driver door to wake up data bus.


**2**  Press UNLOCK on OEM remote.  
  
(If the vehicle is not equipped with an OEM remote, press on the module programming button.)

**3**  Wait, LED will flash BLUE once [1x]. If LED does not flash GREEN, repeat step 2.


**4**  Set ignition to ON position.



**5**  Wait, if LED turns solid RED proceed to step 6.  
If LED flashes BLUE rapidly, proceed to step 10.


**6**  Set ignition to OFF position.




**7**  Repeat steps 4 to 6, eight times [8x].


**8**  Set ignition to ON position.




**9**  Wait, LED will flash BLUE rapidly.


**10**  Set ignition to OFF position.




**11**  **WARNING:**  
Disconnect power last.  
Disconnect module from vehicle.


**12**  Connect module to computer and proceed with extended programming.

**13**  **WARNING:** Do not press module programming button.  
Connect power first.  
Connect module to vehicle.

**14**  Set ignition to ON position.



**15**  Wait, LED will turn solid BLUE for 2 seconds.

**16**  Set ignition to OFF position.



**17** Module Programming Procedure completed.

## WARNING: READ BEFORE REMOTE STARTING THE VEHICLE

### IMPORTANT

- I All vehicle doors must be closed and locked prior to remote start sequence. Failure to comply will result in remote starter malfunction.

## TAKE OVER PROCEDURE - PTS - TO THE VEHICLE OWNER

### NOTE

- I All vehicle doors must be closed and locked prior to remote start sequence.




**TIME RESTRICTION COMING UP !**

1



Unlock vehicle door using OEM or after-market remote, or door request switch.

2



### TIME RESTRICTION

Within 45 SECONDS from previous step:

Open vehicle door.  
Enter vehicle.  
Close vehicle door.

Press and release BRAKE pedal.

3

Take over procedure completed.



Failure to follow procedure will result in vehicle engine shutdown.