

Make	Model	Year	Install	CAN	Lights	IGN	RAP	I/O Changes
DL-CH12 Chrysler	Pacifica PTS	2017	Type 1B	OBD-II	Park / Auto Type B2	PINK	NO	Green White/Blue N/A

### FIRMWARE:

Esta instalación requiere BLADE-AL (DL) -CH12, módulo flash y actualización del firmware del controlador antes de la instalación.

### INSTALACIÓN:

Los vehículos de tipo 1B utilizan conexiones CAN en el arnés en el conector OBD-II, no se requiere la extensión CAN incluida para este tipo de instalación.

### ENCENDIDO:

La ignición está disponible en el conector de unión ubicado sobre el panel de protección del conductor, conectado al cortafuegos, cable del vehículo se encuentra en el pin # 37, rosa / lt. verde, del conector de 59 pines.

## FTI-CDP1 - Notas de instalación y configuración

- A** CONEXIÓN REQUERIDA (OBD-II CAN)
- B** NO SE REQUIERE (extensión CAN)
- C** SIN CONEXIÓN
- D** CONEXIÓN REQUERIDA (IGN)



COBERTURA DE FUNCIONES																				
IMMOBILIZER DATA	ARM OEM ALARM	DISARM OEM ALARM	DOOR LOCK	DOOR UNLOCK	PRIORITY UNLOCK	TRUNK/HATCH RELEASE	POWER LIFTGATE	POWER SLIDING DOOR (L)	POWER SLIDING DOOR (R)	SECURE TAKEOVER	DOOR STATUS	TRUNK STATUS	HOOD STATUS	E-BRAKE STATUS	TACH OUTPUT	BRAKE STATUS	GLOW PLUG STATUS	PARKING LIGHTS	HAZARD LIGHTS	A/M CONTROL

•FT-DAS Required for manual transmission.  
•BOTH Red & Red/White MUST be connected with high current application.



**Jumper Setting**

**CM7000/7200** Cut loop for A/T


**CM-900S/900AS**

**CM900AS/900S Jumper**

START  
ACC  
IGN1




**OBD-II connector**



**PTS Button**




**Headlight switch**



**Driver kick panel/firewall junction connector**

Junction connector, above driver kick panel, attached to firewall



pink/lt. green

**Códigos de error de programación de LED**

El LED del módulo parpadea en ROJO durante la programación


- 1x - Error de CAN
- 2x - Código clave no aprendido
- 3x - Sin ENCENDIDO
- 4x - Sin inmovilizador, comprobar CAN / llave
- 5x - Error de VIN, verifique el cableado CAN
- 6x - Ver error 4x
- 7x - Error de KLON
- 8x - Sin ENCENDIDO, verifique la conexión


## MODULE PROGRAMMING PROCEDURE - PTS

### NOTE

I **IMPORTANT:** The hood must be closed.


1  Close driver door.  
Re-open driver door to wake up data bus.


2  Press UNLOCK on OEM remote.  
  
(If the vehicle is not equipped with an OEM remote, press on the module programming button.)


3  Wait, LED will flash BLUE once [1x]. If LED does not flash GREEN, repeat step 2.


4  Set ignition to ON position.




5  Wait, if LED turns solid RED proceed to step 6.  
If LED flashes BLUE rapidly, proceed to step 10.


6  Set ignition to OFF position.




7  Repeat steps 4 to 6, eight times [8x].

8  Set ignition to ON position.



9  Wait, LED will flash BLUE rapidly.


10  Set ignition to OFF position.




11  **WARNING:**  
Disconnect power last.  
Disconnect module from vehicle.


12  Connect module to computer and proceed with extended programming.

13  **WARNING:** Do not press module programming button.  
Connect power first.  
Connect module to vehicle.

14  Set ignition to ON position.



15  Wait, LED will turn solid BLUE for 2 seconds .

16  Set ignition to OFF position.



17 **Module Programming Procedure completed.**

## WARNING: READ BEFORE REMOTE STARTING THE VEHICLE

### IMPORTANT

- I All vehicle doors must be closed and locked prior to remote start sequence. Failure to comply will result in remote starter malfunction.

## TAKE OVER PROCEDURE - PTS - TO THE VEHICLE OWNER

### NOTE

- I All vehicle doors must be closed and locked prior to remote start sequence.




TIME RESTRICTI ⌚ ON COMING UP !

1



Unlock vehicle door using OEM or after-market remote, or door request switch.

2



TIME RESTRICTI ⌚ ON

Within 45 SECONDS from previous step:

Open vehicle door.  
Enter vehicle.  
Close vehicle door.

Press and release BRAKE pedal.

3

Take over procedure completed.



Failure to follow procedure will result in vehicle engine shutdown.